

ALIBI RISER (H-D 883 & 1200) MOUNTING APPLICATION
DETERMINE IF A HIGH OR LOW MOUNT FITS BEST
SECURE BRACKET TO THE BACK OF THE TOOL ROLL
WITH THE BUTTON HEAD SCREWS AND LOCK NUTS
PROVIDED. ALIGN THE BRACKET WITH THE CUT-OUT
SIDE OUTBOARD. USE THE HANDLEBAR RISER
BOLTS* TO SECURE THE BRACKET.

* LONGER BOLTS MAYBE REQUIRED

